

021000

Illustrated Parts List

Model Series

021000

TYPE NUMBERS
0111 through 0111.

For Use On Engines Built Before Date Code – 01093000


TABLE OF CONTENTS

Air Cleaner	3
Blower Housing/Shrouds	4
Cams	2
Carburetor	3
Crankcase Cover/Sump	2
Crankshaft	2
Cylinder	2
Flywheel	2
Fuel Tank	4
Head	2
Ignition	4
Kits/Gaskets – Carburetor	3
Kits/Gaskets – Engine	2
Muffler	4
Oil	2
Piston Group	2
Rewind	4
Valves	2






PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6848-3 Assemblies include all parts shown in frames.



1036 EMISSION LABEL
 1019 LABEL KIT

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	696946	Cylinder Assembly	117	●696992	Jet–Main (Standard)	621	696882	Switch–Stop
3	★696879	Seal–Oil (Magneto Side)	121	697008	Kit–Carburetor Overhaul	654	690800	Nut (Carburetor)
5	696848	Head–Cylinder	122	★696870	Spacer–Carburetor	676	697039	Deflector–Muffler
7	★696865	Gasket–Cylinder Head	125	696949	Carburetor	677	697040	Screw (Muffler Deflector)
9	★696931	Gasket–Breather	174	696993	Throttle Valve Assembly	773	696969	Retainer
11	696871	Tube–Breather	187	696935	Line–Fuel	842	★691876	Seal–O Ring (Dipstick Tube)
12	★696866	Gasket–Crankcase	191	696922	Gasket–Fuel Tank	868	696873	Seal–Valve
13	696891	Screw (Cylinder Head)	240	696918	Filter–Fuel	883	★697035	Gasket–Exhaust
16	696985	Crankshaft	279	696889	Screw (Valve Cover)	957	696921	Cap–Fuel Tank (Plastic)
17	696883	Bearing–Ball	300	696874	Muffler	968	696924	Cover–Air Cleaner
18	696950	Cover–Crankcase	306	696936	Shield–Cylinder	972	696919	Tank–Fuel (Plastic)
22	696889	Screw (Crankcase Cover/ Sump)	307	696889	Screw (Cylinder Shield)	976	●696989	Primer–Carburetor
23	696885	Flywheel	307A	696895	Screw (Cylinder Shield)	977	●697001	Gasket Set–Carburetor
25	696932	Piston Assembly	332	696928	Nut (Flywheel)	994	697038	Arrestor–Spark
26	696933	Ring Set	333	696877	Armature–Magneto	1019	697060	Kit–Label
27	696888	Lock–Piston Pin	334	696891	Screw (Magneto Armature)	1036	697034	Label–Emission
28	696852	Pin–Piston	337	696876	Plug–Spark	1238	696893	Screw (Carburetor Spacer)
29	696878	Rod–Connecting	358	697010	Gasket Set–Engine	1245	696967	Cover–Cam Gear
33	696862	Valve–Exhaust	365	696894	Screw (Carburetor)	1246	696929	Gasket–Cam Gear Cover
34	696864	Valve–Intake	391	696991	Body–Fuel Pump	1247	696889	Screw (Cam Gear Cover)
35	696863	Spring–Valve (Intake)	393	●697006	Screen–Carburetor	1248	696947	Blower Housing/ Rewind
36	696863	Spring–Valve (Exhaust)	471	696995	Screw (Inlet Seat) (Metering Lever Pin)	1249	696889	Screw (Blower Housing/ Rewind)
40	696851	Retainer–Valve	507	696872	Insulator	1253	696909	Check Valve– Breather Tube
45	696853	Tappet–Valve	523	696930	Dipstick	1255	697007	Screw (Primer Bulb Cover)
46	696984	Camshaft	535	696923	Filter–Air Cleaner Foam	1256	697045	Cover–Primer Bulb
51	★●696868	Gasket–Intake	551	696849	Cover–Valve	1257	697046	Backplate–Primer
51A	★696867	Gasket–Intake	573	696925	Plate–Back			
56	696975	Pulley–Starter						
57	696976	Spring–Rewind Starter						
58	696973	Rope–Starter						
60	696974	Grip–Starter Rope						
104	●696996	Pin–Float Hinge						
106	●696988	Seat–Inlet						

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

∅ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.