

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.



Ref #	Part Number	Qty	Description
1	772097A		Transaxle Cover
2	780155		Needle Bearing
3	770088		Transaxle Case
4A	776276A		Countershaft
5	776275		Output Shaft (9 teeth)
6B	778247		Output Gear (35 teeth-steel)
7	778253		Spur Gear (15 teeth-steel)
8	792123A		Key
9	784216		Shift Collar
10	784342		Shift Rod & Fork
11	778246		Bevel Gear (33 teeth-steel) (NOTE: This model requires that the bevel gear be in a reversed position, therefore placement of the bearing 780071 and washers 780072 & 780153 should be as shown in the boxed inset on the illustration.)
12	778245		Input Bevel Pinion (13 teeth-steel)
13	778198		Bevel Gear (steel)
14	778197		Differential Bevel Pinion (steel)
15	778248		Ring Gear (31 teeth)
16	786027		Drive Block
17	786019		Drive Pin
18A	786121		Neutral Spacer (.350/.340 thick)
18	786122		Neutral Spacer (.276/.268 thick)
20	792077A		Steel Ball
21	792078		Set Screw, 3/8-16 x 3/8"
22	792079		Spring
24	780071		Thrust Bearing (NOTE: This model requires that the bevel gear be in a reversed position, therefore placement of the bearing 780071 and washers 780072 & 780153 should be as shown in the boxed inset on the illustration.)
25A	792073A		Screw, 1/4-20 x 1-1/4"
25	792129A		Screw, 5/16-18 x 1-1/4"
26	792018		Snap Ring
27	792018		Snap Ring
28	788040		Retaining Ring
29	780072		Thrust Washer (NOTE: This model requires that the bevel gear be in a reversed position, therefore placement of the bearing 780071 and washers 780072 & 780153 should be as shown in the boxed inset on the illustration.)
30	780108		Thrust Washer
31	780128		Thrust Washer
31A	780107		Washer
31B	780042		Thrust Washer
36	790043		Brake Disk
37	790007		Brake Pad Plate
38	799021		Brake Pad (pkg of 2)
39	786026		Dowel Pin
40	792076A		Flat Washer
41	790016		Brake Lever
42A	792085A		Screw, 1/4-20 x 2-1/4"
42	792073A		Screw, 1/4-20 x 1/4"
43	792075		Locknut, 5/16-24
44	790025		Brake Pad Holder
45	786092		Spacer
46	786086		Brake Lever Bracket

820-820-002B Page 2 of 4  
Peerless

Ref #	Part Number	Qty	Description
47	774796A		Axle (12-1/4" long)
48	774795A		Axle (26-1/4" long)
49	778207A		Spur Gear (37 teeth-steel)
50	778206A		Spur Gear (35 teeth-steel)
51	778239A		Spur Gear (32 teeth-steel)
52	778205A		Spur Gear (30 teeth-steel)
53	778204A		Spur Gear (25 teeth-steel)
54	778219		Spur Gear (20 teeth-steel)
56	778211		Spur Gear (12 teeth-steel)
57	778199		Spur Gear (15 teeth-steel)
58	778240		Spur Gear (18 teeth-steel)
59	778200		Spur Gear (20 teeth-steel)
60	778201	820-820-0025	Spur Gear (25 teeth-steel)
61	778222	Peerless	Spur Gear (30 teeth-steel)
65	780109		Thrust Washer (flat)
66	776274		Input Shaft (3.866" long)
67	776314		Brake Shaft (4 keyed)
69	780051		Thrust Washer
71	788069		Square Cut Seal
71A	792145		Pushnut
72	792074		Threaded Plug, 9/16-18
79	792144		Brake Spring
81	786081		Roller Chain (No. 41 chain, 24 links)
82	786082		Sprocket (9 teeth)
83	786123		Sprocket (18 teeth)
84	786131		Bearing Cap
87	788042		Oil Seal
88	780119		Ball Bearing
89	780050		Ball Bearing
90	788067B		Grease (32 oz. bottle Bentonite greas e)
96	780084		Thrust Bearing
97	780051		Thrust Washer
98	780165		Flat Washer
99	788077		"O" Ring
100	780166		Cupped Washer
101	774833		Differential Carrier (threaded holes)
102	774834		Differential Carrier
103	792020		Screw, 1/4-20 x 2-1/4"
104	792006		Lockwasher, 1/4"
105	780153		Washer (NOTE: This model requires that the bevel gear be in a reversed position, therefore placement of thebearing 780071 and washers 780072 & 780153 should be as shown in the boxed inset on the illustration.)
106	786144		Sleeve
107	780150		Needle Bearing
108	780152		Needle Bearing (capped)
109	792001		"O" Ring
110	786142		Sleeve (stepped)
111	788071		Square Cut Ring
112	780168		Needle Bearing (capped)
113	786143		Sleeve (stepped)
114	780151		Needle Bearing (capped)
115	786145		Sleeve (stepped)
116	788070		Square Cut Ring
117	780031		Needle Bearing

---

Ref #	Part Number	Qty	Description
150	510334		Gasket Eliminator (Loctite #515)

---