

**WARNING**  
 All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Gasket Kit

103.

Ref #	Part Number	Qty	Description
1	530036677		Upper Handle
2	530036985		Handle Eyelet
3	530015241		Screw-Eyelet
4	530036981		Spring Isolator
5	530036676		Lower Handle
6	530015768		Locknut-Coupling/Shaft
7	530036982		Throttle Spring
8	503210719		Screw-Handle
9	530036673		Throttle Trigger
10	530036984		Handle Spring
11	530095104		Upper Handle Tube
12	530015999		Screw-Shaft
13	530036983		Coupling Handle
14	530016002		Bridgepin
15	530015997		Axle Pin
16	530095126		Rear Wheel
17	530015982		Tube Clamp
18	530095103		Lower Handle Tube
19	530015983		Screw-Filter Cover
20	530036632		Type 1 & 2
20	530038037		Type 3
21	530036837		Gasket
22	530036664		Air Filter Foam
23	530036674		Throttle Cable
24	530016038		Boot w/Nut
25	530038474		Switch Indicating Plate
26	530037066		Grounding Terminal
27	530014707		Switch Grounding Assy (Incl. 24-26)
28	530015922		Speed Nut
29	530015774		Screw-Fan Housing
30	530015886		Screw-Fan Housing
31	530015810		Screw-Fan Housing/Shroud
32	530036656		Type 1 & 2
32	530047946		Type 3 (Kit - Incl. 73 & 101)
33	530036927		Flywheel Spacer
34	530015828		Washer
35	530038302		Axle Cover
36	530015940		Screw-Fan Housing
37	530015954		Screw-Ignition Module
38	530014655		Switch Wire Ass'y.
39	530039163		Ignition Module
40	530036145		Spacer-Ignition Module
41	530027569		Starter Handle
42	530069421		Rope Kit
43	530015774		Screw-Coupling
44	530039149		Flywheel Ass'y.
45	530015945		Retaining Ring-C'case
46	530019179		C'case Seal
47	530014861		Crankcase Ass'y. (Incl. 45, 46, 51 & 52)
48	530014864		Crankshaft Ass'y.
49	530019181		Gasket-Crankcase
50	530038035		Shroud
51	530032124		Outer Bearing
52	530015941		Retaining Ring-C'shaft
53	530032125		Inner Bearing
54	530036404		Piston Ring

PP135 Gas Engine Page 2 of 6  
ASSEMBLY Coupling Handle

Ref #	Part Number	Qty	Description
55	530015934		Screw-Shroud
56	530069615		Connecting Rod Ass'y. (Incl. 53)
57	530015162		Piston Pin Retainer
58	530019223		Gasket-Cylinder
59	530069620		Piston Kit (Incl. 54)
60	530015953		Screw-Cylinder
61	530030075		Spark Plug (RCJ-8Y)
62	530069618		Cylinder Kit
63	530019185		Gasket-Cylinder/Carb Adaptor
64	530038036		Carb. Adaptor
65	530016014		Screw-Carb Adaptor
66	530019194		Carb. Gasket
67	530035328		Type 1 & 2 (WT 242)
67	530069654		Type 3 (WT 308)
68	530036626		Air Box Base
69	530019190		Foam Seal
70	530036622		Airbox Cover
71	530015887		Screw-Airbox Cover
72	530023877		Fuel Line Fitting
73	530038308		Fuel Line Retainer
74	530036180		Muffler Screen
75	530019144		Gasket-Carb.
76	530029930		Muffler Spring
77	530016033		Washer-Blade
78	530016032		Nut-Blade
79	530069660		Muffler Kit (Incl. 73-78)
80	530037229		Starter Spring
81	530069418		Starter Pulley Kit (Incl. 3, 83 & 85)
82	530037224		Eyelet
83	530036679		Rope Retainer
84	530019199		Gasket-Tube
85	530027162		Starter Dog
86	530042073		Starter Cam
87	530042072		Starter Dog Wire
88	530036922		Starter Cup
89	530014832		Clutch Ass'y.
90	530015127		Washer-Belleville
91	530069599		Fuel Line Kit
92	530014815		Fuel Pick-up Ass'y.
93	530014347		Fuel Cap Ass'y.
94	530047195		Fuel Tank Ass'y.
95	530036792		Fuel Tank Isolator
96	530626605		Nut
97	530036665		Drum Clutch
98	530095082		Front Shield
99	530015843		Screw
100	530036935		Dustplug
101	530015770		Screw-Bearing Holder
102	530036934		Type 1
102	530037367		Type 2 & 3
103	530069624		Gasket Kit (Incl. 21,49,58,63,66,75)
104	530095086		Blade
105	530014906		C'case & C'shaft Ass'y. (Incl. 45-48, & 51-53)
106	530037625		Retainer Ring
107	530016067		Shoulder Bolt
108	530016040		Washer

PP135 Gas Engine Page 3 of 6  
ASSEMBLY Type 1 & 2 (WT 242)

Ref #	Part Number	Qty	Description
109	530095070		Drive Shaft
110	530015814		Screw
111	530014894		Gear Box Ass'y.
112	530036675		Back Plate
113	530036923		Spring
114	530036683		Height Lever
115	530027163		Retainer-Starter Pulley
116	530016063		Nut-Swing Arm
117	530015981		Bolt-Front Wheel
118	530095125		Front Wheel
119	530037279		Swing Arm
120	530015515		Locknut-Swing Arm
121	530036884		Front Axle Spring
122	530001717		Washer-Thrust
123	530015151		Washer-Flat
124	530016042		Washer-Thrust
0	530068543		Operator Manual, Type 1 & 2 Not Shown.
0	530082472		Operator Manual, Type 3 Not Shown.
0	530014658		Operator Manual, Carton Contents Bag Not Shown.
0			Operator Manual, Starting Instruction Decal Not Shown.
0	530037713		Operator Manual, Type I Not Shown.
0	530037582		Operator Manual, Type 2 Not Shown.
0	530047457		Operator Manual, Type 3 Not Shown.
0	530036658		Operator Manual, Blade Shield Decal (Not a serviceable part) Not Shown.
0	530031111		Operator Manual, Hex Wrench 5/32 Not Shown.

PP135 Gas Edge Page 4 of 6  
ASSEMBLY

# Carburetor Assembly

**Type 1 & 2**  
**WT 242 - #530-035328**

**Type 3**  
**WT 308 - #530-089854**

Gasket/Dia.  
Repair Kit


12

Carburetor  
Repair  
Kit

13

Primer  
Bulb  
Repair Kit

14



Ref #	Part Number	Qty	Description
1	530035164		Pump Gasket Types 1 & 2
2	530035166		Pump Diaphragm Types 1 & 2
3	530035178		Fuel Inlet Screen Types 1 & 2
4	530035319		Welch Plug Types 1 & 2
5	530035139		Metering Lever Spring Types 1 & 2
6	530035250		Metering Pin Types 1 & 2
7	530035223		Inlet Needle Valve Types 1 & 2
8	530035236		Metering Lever Pin Screw Types 1 & 2
9	530035031		Metering Lever Types 1 & 2
10	530035320		Metering Diaphragm Gasket Types 1 & 2
11	530035014		Metering Diaphragm Types 1 & 2
12	530035313		Gasket/Diaphragm Kit (Incl. 1, 2, 10 & 11)
13	530035312		Carburetor Repair Kit Type 1 & 2 (Inc. 1-12)
13	530069658		PP135 Gas Carburetor Repair Kit Type 1 & 2 (Inc. 1-12) CARBURETOR SWT342-WT Type 3 (BCT indicates Contents on illus.)
15	530038317		Limiters Cap-Low Type 3
16	530038318		Limiters Cap-High Type 3

PP135 Gas Carburetor Repair Kit Type 1 & 2 (Inc. 1-12)  
CARBURETOR SWT342-WT  
Type 3 (BCT indicates Contents on illus.)