



▲ WARNING
 All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref #	Part Number	Qty	Description
1	530069863		Handle Kit
2	530026994		Isolator
3	530029111		Spacer-Isolator
4	530015635		Screw
5	530029130		Isolator-Handle (Rear)
6	530015813		Screw
7	530029072		Trigger
8	530027597		Spring-Lever Return
9	530015702		"C" Clip-Throttle Lock
10	530029117		Throttle Lock Button
11	530015840		Pin-Handle
12	530024772		Spring-Throttle
13	530052458	SB180BV	Shroud-Left
14	530052457	Blower Assembly	Shroud-Right
15	530053346		Heat Shield
16	530069572		Switch Kit
17	530029129		Isolator-Engine Mount
18	530029295		Isolator Tank
19	530015814		Screw
20	530014263		Fuel Tank Ass'y. (Incl. #21, 22 & 80)
21	530014347		Fuel Cap Ass'y.
22	530014362		Fuel Pick-up Ass'y.
23	530014160		Handle Cover Ass'y. (Incl. #9, 10 & 12)
24	530052456		Cover-Filter
25	530029112		Air Filter (Foam)
26	530029404		Air Baffle
27	530069293		Muffler Kit
28	530029116		Spring-Muffler
29	952030201		Spark Plug (RCJ-8Y)
30	530001624		Screw
31	530069626		Cylinder Kit
32	530029425		Lead Wire (Switch)
33	530039137		Ignition Module
34	530015816		Screw
35	530019178		Gasket-Cylinder
36	530025875		Piston Ring
37	530069349		Piston Kit (Incl. #36, 38, & Pin)
38	530015162		Retainer
39	530015306		Screw
40	530029426		Ground Wire (Switch)
41	530015849		Screw
42	530015254		Washer
43	530015852		Spacer-Choke
44	530029114		Choke Shutter
45	530015775		Screw
46	530037492		Cable Assembly
47	530029115		Plate-Air Filter Mtg.
48	530069644		Carburetor Ass'y. Kit (WT 141A w/ Limiter Cap)
49	530019164		Gasket - Carb
50	530019165		Seal - Foam/Reed Block
51	530015771		Screw
52	530029113		Ground Wire (Static)
53	530047696		Reed Block/Heat Shield
54	530019166		Gasket-Reed Block/C'case
55	530027593		Reed Valve
56	530027594		Reed Stop

Ref #	Part Number	Qty	Description
57	530016064		Screw
58	530047669		Crankshaft Ass'y.
59	530015126		Flywheel Key
60	530010960		Connecting Rod Ass'y.
61	530069232		Rope Kit
62	530032103		Inner Bearing
63	530015787		Retaining Ring
64	530019158		Crankshaft Seal
65	530032102		Outer Bearing
66	530015789		Retaining Ring (Shaft)
67	530014016		Crankcase Ass'y.
68	530039189		Flywheel Ass'y. (Incl. #70)
69	530347987	SB180BV Washer	Washer
70	530023817	Blower Assembly	Spring-Starter Dog
71	530038386		Spacer-Flywheel
72	530047705		Crankcase/Crankshaft Assy. (Incl. #58 & 62-67)
73	530016080		Screw
74	530015496		Screw
75	530027523		Retainer
76	530069486		Starter Pulley Kit (Incl. #73)
77	530042085		Starter Spring
78	530069714		Fan Housing Kit (Incl. #61, 71, 73-77, 79 & 86)
79	530027569		Starter Handle
80	530069247		Line Kit
81	530015769		Screw
82	530015815		Screw
83	530015672		Spring-Torsion (Left)
84	530069348		Spark Arrestor Kit
85	530019167		"O" Ring-Seal
86	530029182		Eyelet-Flange
87	530015647		Pin-Pivot
88	530049185		Sponge-Air Dam
89	530029119		Tube - Rope Retainer
90	530094710		Blower Housing (Upper)
91	530029173		Band-Blower Hsg.
92	530014157		Impeller Ass'y. (Incl. Hub)
93	530015667		Spring-Torsion (Right)
94	530047700		Inlet Door
95	530015441		Washer-Conical
96	530001733		Nut
97	530047736		Blower Housing (Lower) (Incl. #82, 83, 87, 93 & 94)
98	530069692		Muffler Guard Kit
99	530069294		Gasket Kit (Incl. #35, 49, 50 & 54)
100	530069961		Tube & Nozzle Kit
101	530015818		Washer-Impeller
	530087854		Operator's Manual (Not Shown)
	530047885		Decal - Door Instruction (Not a serviceable part) (Not Shown)
	530047876		Decal - Blower Warning (Not Shown)
	530031159		Hex Wrench (5/32) (Not Shown)



Ref #	Part Number	Qty	Description
	530069644		Carburetor Assembly - WT 141A
1	530069827		Carburetor Repair Kit (KIT = Indicates Contents)
2	530038403		Limiter Cap
3	530069844		Gasket/Diaphragm Kit (DOT = Indicates Contents)
4	530035341		Needle-Fuel Mixture
5	530035342		Spring-Fuel Mixture



Ref #	Part Number	Qty	Description
1	530095358		Vac Bag Assy. w/Strap
2	530095117		Elbow-Vac Bag
3	530069270		Vac Tube Ass'y.
