

Ref #	Part Number	Qty	Description
1	530094712		Handle
2	530026994		Front Isolator
3	530029111		Spacer
4	530015635		Screw-Handle
5	530029130		Rear Isolator
6	530015813		Screw
7	530029072		Trigger
8	530027597		Spring
9	530015702		"C" Clip
10	530029117		Throttle Lock Button
11	530015840		Pin
12	530024772		Spring-Throttle Lock
13	530037503		Shroud-Left
14	530037143		Shroud-Right
15	530019168		Grommet-Carb.
16	530069572		Switch Kit
17	530029129		Isolator-Engine Mount
18	530029295		Isolator-Tank
19	530015814		Screw-Shroud/Blower Hsg.
20	530014263		Fuel Tank Ass'y.
21	530014347		Fuel Cap (Incl. O'Ring)
22	530014362		Fuel Pick-up Ass'y.
23	530014160		Handle Cover/Throttle Lock Ass'y. (Incl. 9, 10 & 12)
24	530029274		Cover-Air Filter
25	530029112		Air Filter
26	530027525		Spacer (Model SV22 only)
27	530069293		Muffler
28	530029116		Spring
29	530030075		Spark Plug
30	530015239		Screw
31	530069627		Model SV22
31	530069626		Model SV30
32	530029425		Lead Wire
33	530039137		Ignition Module
34	530015776		Model SV22
34	530015816		Model SV30
35	530019178		Gasket-Cylinder
36	530026413		Model SV22 (1 ring)
36	530025875		Model SV30 (2 rings)
37	530069274		Model SV22
37	530069349		Model SV30
38	530015162		Retainer
39	530015306		Screw
40	530029426		Ground Wire
41	530015849		Screw
42	530015254		Wave Washer
43	530015852		Spacer-CHoke
44	530029114		Choke Shutter
45	530015771		Screw-Reed
46	530037492		Throttle Cable Assembly
47	530029115		Plate-Air Filter
48	530069644		Carburetor Ass'y. (WT-141A) (Incl. Limiter Cap)
49	530019164		Gasket-Carb
50	530019165		Seal-Reed Block
51	530015775		Screw
52	530029113		Ground Wire-Static

SV22 Gas Blower Page 2 of 8  
 BLOWER ASSEMBLY

Ref #	Part Number	Qty	Description
53	530047696		Reed Block
54	530019166		Gasket-Reed Block
55	530027593		Reed Valve
56	530027594		Reed Stop
57	530016064		Screw
58	530047669		Crankshaft
59	530015126		Key
60	530014005		Model SV22
60	530010960		Model SV30
61	530069232		Rope Kit
62	530032103		Inner Bearing
63	530015787		Retaining Ring-Crankcase
64	530019158		Crankshaft Seal
65	530032102		Outer Bearing
66	530015789		Retaining Ring-Crankshaft
67	530014016		Crankcase Ass'y (Incl. 62-65)
68	530039189		Flywheel Ass'y. (Incl. 70)
69	530347987		Washer
70	530023817		Spring
71	530047701		Spacer-Flywheel
72	530047705		Crankcase/Crankshaft Assy. (Incl. 58, 62-67)
73	530016080		Screw
74	530015496		Screw
75	530027523		Retainer
76	530069486		Starter Pulley (Incl. 73)
77	530029395		Starter Spring
78	530069714		Fan Housing Kit (Inc.61,71,73-76,79,86)
79	530027569		Starter Handle
81	530015769		Screw
82	530031111		Hex Wrench 5/32"
83	530069692		Muffler Guard Kit (Incl. 82)
84	530029404		Air Baffle
85	530019167		"O" Ring
86	530029182		Eyelet
87	530015805		Screw
88	530095355		Mulch Blade
89	530029119		Roll Pin
90	530094710		Blower Housing (Upper)
91	530029173		Band
92	530047702		Impeller (Incl. 93)
93	530029118		Hub-Impeller
94	530069294		Gasket Kit
95	530015441		Washer
96	530001733		Nut
97	530047736		Blower Housing (Lower) (Incl. 99-103)
98	530069247		Line Kit
99	530047700		Door-Inlet
100	530015667		Spring-Right
101	530015647		Pin
102	530015815		Screw
103	530015672		Spring-Left
104	530069348		Spark Arrestor Kit
105	530038508		Ass'y-Tube and Nozzle
	530083733		Operators Manual Not Shown.
	530047876		Decal-Blower Warning Not Shown.

SV22 Gas Blower Page 3 of 8  
BLOWER ASSEMBLY

Ref #	Part Number	Qty	Description
	530047554		Decal-Instruction (Not a serviceable part) Not Shown., (Not a serviceable part)


SV22 Gas BlowerPage 4 of 8  
BLOWER ASSEMBLY



---

Ref #	Part Number	Qty	Description
1	530069725		Carburetor Repair Kit Parts indicated by an . in illustration are for clarity only, order complete assembly.
2	530038403		Limiter Cap

SV22 Gas BlowerPage 6 of 8  
CARBURETOR



---

Ref #	Part Number	Qty	Description
1	530095358		Collection Bag
2	530069750		Vacuum Tubes
3	530095359		Vacuum Elbow

---

SV22 Gas BlowerPage 8 of 8  
VACUUM ASSEMBLY