



Ref #	Part Number	Qty	Description
1	530400247		Housing Ass'y.
2	530400205		Switch Button
3	530400206		Screw
4	530400241		Circuit Board/Motor Ass'y.
5	530400204		Battery
6	530400207		Palnut
7	952701617		Replacement Line
8	530400233		Charger
9	530400230		Decal
10	530400235		Operators Manual
11	530400208		Retainer
	530400232		Carton
			CLIPQUIK Cordless Sander
			CLIP QUIK ASSEMBLY