



Ref #	Part Number	Qty	Description
1	530340179		Screw
2	530403324		Trigger Lockout
3	530403325		Wrist Support Cushion
4	530403326		Battery Door
5	530015994		Screw
6	530403328		Probe - Clamp
7	530403329		Wire Harness Ass'y.
8	530403330		Assist Handle Cushion
9	530403331		Wall Bracket
10	530403332		Trigger Switch
11	530403333		Battery Hsg. Set
12	530053401		Battery
13	530403335		Handystik Life Tube w/ Warning Decal
14	530403336		Trimmer Assembly
15	530403337		Motor Hsg. Set w/ Line Limiter
16	530015775		Motor/Hub Ass'y.
17	530403338		Screw
18	530403329		Clamp - Motor
19	530053405		Battery Spring
20	530403395		Charger
21	530403010		Spring
22	530401467		Retainer Spring
23	952711527		Screw w/Washer
24	530403443		Spool w/Line
	530084351		Lockout Spring
	530403470		Operator Manual Not Shown
	530403471		Wall Anchor Not Shown
	530053399		Screw Not Shown
			Warning Decal Not Shown