


**WARNING**

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

NOTE: Model 500 Includes Key No.'s 2, 11, 12, 13, 14 and Decal "A".



Ref #	Part Number	Qty	Description
1	530093846	1	Arbor Shaft
2	530092243	4	Screw - Bearing Housing 1/4 Plastite
3	530015518	1	Screw - Tapping # 10-16-1/4
4	530091783	2	Retaining Ring
5	530092216	1	Washer - Dust Cup
6	530092359	1	Dust Cup
7	530092227	1	Washer - 1/4 - 20 Interlock
8	530625509	1	Screw - 1/4 - 20x 1 (Hex Head)
9	530093214	1	Bearing Housing Ass'y (incl, #'s 1,4-8 & 10)
10	530069086	1	Bearings and Spacer
11	530093159	1	Housing - Upper Impeller
12	530093162	1	Impeller
13	530093161	1	Housing - Lower Impeller
14	530015367	6	Screw - Impeller Housing Ass'y # 10 Plastite
15	530091373	1	Wing Nut - "D" Handle
16	530015149	1	Washer - "D" Handle
17	530094528	1	Drive Shaft Ass'y (incl. # 20)
18	530010722	1	"D" Handle
19	530092061	1	Screw - "D" Handle
20	530093213	1	Flexible Drive Shaft
21	952701570	1	Flex Shaft Lube
0	530066954	1	Operator's Manual (not shown)
A	026445	1	Decal - Warning/Product
0	530027430	1	Decal - Safety Label

510 Electric Blower Page 2 of 2

POWER ATTACH